

# SimPal-T40

# SimPal-T20

GSM Power Socket



Free APP " SimPal-T40 "



Available on  
Google Play



Available on  
App Store

## User Manual

Manual version 3.0



## SimPal-T40/T20 GSM Power Socket

Thank you for purchasing the SimPal-T40/T20.

SimPal-T40 GSM power socket is a remote-controlled socket consisting of a GSM module. The power supply output can be turned on or off remotely by the SMS command or voice calling.

SimPal-T20 slave socket need to work with T40 Master socket, It can control one T40 and four T20 with one SIM card.

Both T20 and T40 socket support temperature monitor, temperature control, schedule control and delay control by sending SMS from your mobile phone.

All services and functions need to be supported by the GSM network and a SIM card.

This brochure suits for **SimPal-T40** and **SimPal-T20** model.

Details of the functioning and advanced operation of this socket are described in this instruction manual.

# CONTENT

For your safety .....	5
Exception clause .....	7
1.1 Package contents .....	8
1.2 Sockets instructions .....	9
1.3 Light indicator .....	11
2.1 User authorization level .....	12
2.2 About the SMS Command .....	13
3.1 Start to use .....	13
3.2 Download “SimPal-T40” APP .....	15
3.3 Register Master-number. ....	16
3.4 Pairing slave socket .....	18
3.5 Turn on/off power .....	19

3.6 Delay control.....	20
3.7 Schedule control .....	22
3.8 Temperature control .....	25
3.9 Temperature alarm .....	27
3.10 Wireless sensor alarm.....	29
3.11 SMS when on/off button pressed .....	31
3.12 Power failure alarm .....	32
3.13 Calling control .....	32
3.14 SMS notification to User .....	33
3.15 Check status.....	34
3.16 Weak GSM signal alarm .....	35
4. Reset factory setting .....	36
5. Main Technical Parameters .....	38
<b>Appendix: SMS commands list .....</b>	<b>39</b>



- 1. Purchase a GSM SIM card (mobile phone card) from GSM network service provider and install it in the socket. This SIM card number is referred as SimPal-T40 number on this brochure.**
- 2. The user needs to activate the Caller ID Presentation function of SIM card, and deactivate PIN code of the SIM. Contact with GSM network service provider for support.**

## **For your safety**

- This socket was designed for home or office use. Do not use it on the electrical appliance which is for industry or business operation, for example, iatrical appliances, large heaters and refrigerates.
- Before using this socket, make sure that the mobile phones can be used well in the area, otherwise, do not put this socket into operation.
- The power consumption of the appliances connected with the socket cannot exceed 3500W and the current cannot exceed 16A.
- The electrical appliance which power consumption is higher than 1500W must be grounded.
- Do not make two plugs of socket short circuit.
- Do not touch the socket jack by any metal objects or hand.
- This socket was designed for indoor use. Don't use it in wet, chemically aggressive or dusty environment. Device working temperature range is  $-10^{\circ}\text{C}\sim+35^{\circ}\text{C}$ , stop to use this product when environment temperature out of working range.


- Do not plug this socket in a row, only allow connect other electricity device on the socket. (nicht hintereinander stecken, nur andere Stromgeräte an der Steckdose anschließen lassen).
- Do not open the case unless maintenance needed by professionals.
- Do not keep shaking or fall down this socket, otherwise it can be damaged.
- This socket is a wireless signal transmission socket. Keep it away from electronic equipment likely to interfere with the wireless signals, in order to avoid signals interference.
- Switch off this socket and mobile phone when entering areas marked "Explosive", "Might explode", "Closed wireless transceiver sockets" etc.
- Do not cast this socket in a fire, as this may cause explosion.
- This socket should only be operated from power approved by the socket manufacturer. The use of any other types of power may damage the socket.
- Keep the socket and its accessories out of the children reach.




## **Exception clause**

1. We operate on a policy of continuous development. We reserve the right to make changes and improvements to any of the sockets described in this document without prior notice.
2. For the latest socket information, please visit: <http://www.simpal.cn>. We don't guarantee for the document veracity, reliability or any content except regulate in proper laws. Including no guarantee for socket suitable market or suitable area promise.
3. We hold no responsibility for the illegal use of this socket.
4. We hold no responsibility for any loss of income or any special, incidental, consequential or indirect damages howsoever caused.
5. The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either expressed or implied, including, but not limited to the accuracy, reliability or contents of this document. We reserve the right to revise this document or cancel some functions at any time without prior notice


## 1.1 Package contents



Power socket  
( 1 unit )




Temperature sensor  
( 1 PC )




User manual  
( 1 PC )

## 1.2 Sockets instructions



**Note: Slave socket T20 without SIM card slot**



**Temperature sensor Instruction**

## 1.3 Light indicator

Model	Indicator	Action	Status
SimPal-T40 and SimPal-20 Power Socket	Power LED	Turning off	Socket power output OFF
		Constant light	Socket power output ON
	Wireless signal LED	Flash slowly	Searching network (SimPal-T40) Lost connection with T40 (SimPal-T20)
		Slowly breath	Working in standby mode.
		Two fast and one slow Flash	Pairing slave socket or pairing wireless sensor status.
		Continues light in 3 seconds	Rest to factory setting
		Flash fast	Process SMS command

## 2.1 User authorization level

Socket settings can be set or adjusted via a SMS command.

There are two mobile phone user controlling levels:

### **Master-user** (“Master”):

Only one **Master** has authorization to use all features of SimPal-T40.

In order to enable all the functions on the socket, the **Master** must store his/ her mobile number in the socket’s memory. Only one **Master**’s mobile number is allowed for a socket.

### **Family** users (“Family”):

There are four families have authorization to use commands of switch on or cut off the socket output, check socket temperature value or receive power status change alert.

**The other mobile phone users** have no authorization to control the socket.

## 2.2 About the SMS Command

- **SMS command format:** #code#content#.
- The maximum digits that are allowed for the phone number is sixteen.
- SimPal-T40 will reply to the user after it receives the SMS command.



### Note

- The “#” symbol must not be ignored when typing an SMS command.
- No allow any space within the commands.

## 3.1 Start to use

- Installed SIM card to SimPal-T40 GSM power socket; you will see a SIM card slot at the side, make the SIM card metal contact upside and hardly push the SIM card until SIM card fixed.
- Insert the temperature sensor into the I/O port until it is seized.



**Power on:**

1. Plug the SimPal-T40 in an AC power socket.

The GSM LED will be flashing slowly for about 15 seconds, and turn to slowly breathe status and beep ring, breathe LED means the socket already register GSM network, its ready to working.

The socket default power output is OFF.

2. Insert the plug of electronic appliance in the SimPal-T40 electrical outlet.
3. **M button** (See 5 on Figure1) can be pressed for about one second to switch on or off the socket output.

After adding user numbers to the socket, users can send SMS command or make calling to control the power supply output.



**Note:**

- 1.If the GSM indicator light is flash slowly all the time, which imply the SIM card working abnormally, all functions of this socket are invalid.
- 2.Check GSM network signal of the using place:



- GSM network's signal strength may affect the socket feature. Therefore, before using, the user should ensure that SimPal-T40 is used in an area with a strong GSM network signal (CSQ higher than 12).
- For the first time use, the user should perform a test-run by sending SMS to the socket. This allows the user to check the GSM network connection of the socket.

### **3.2 Download “SimPal-T40” APP**

We offer free APP to work with SimPal-T40, search “SimPal-T40 GSM Socket” on Google Play or Apple APP Store, download and install the APP, then it can use APP to control SimPal-T40.

First time register device on APP, input device name and SIM card number which installed on SimPal-T40 device. The APP will create SMS content, send the SMS to device, it will operate according APP function description.

Even without APP, user can send SMS manually according following instruction.

### 3.3 Register Master-number.

Sending following SMS to socket SIM card number from your mobile phone (the phone number will be the **Master** number):

**Register Master-number:** #00# (1)

#### 3.3.1 Change Master number

**Master** sends following SMS message in order to:

**Change master-number:** #14#*NewMasterNumber* (2)

- *NewMasterNumber* should be the new Master mobile phone number.

#### 3.3.2 Register Family-number

Up to 4 Family-number can be stored on GSM socket.

**Family-number** have the authority to send SMS command to switch on or cut off the



### 3.4 Pairing slave socket

**Master** sends SMS to pairing slave socket SimPal-T20 with Master SimPal-T40 GSM socket, before pairing, need to make sure T20 reset factory setting, if the T20 already paired with other T40 before, need to keep press T20 M button for 10 seconds to reset factory setting. Master send following SMS message in order to:

**Pairing Slave socket:** #60#name# (7)

After receive SMS reply “Power on “name” socket now! ”, plug the T20 socket to main power, T20 LED flash slowly for some seconds and go to slowly breath status after connected with T40 socket.



#### Note

- “name” is the slave socket ID communicate with GSM socket, operate slave socket by sending SMS request included “name” in SMS command.

- Request different T20 “name” for one GSM socket.
- “Name” only can be English letter or digital number, max 7 characters.

**Master** sends following SMS message in order to:

**Remove slave socket:** #71#name# (8)

**Remove all slave socket:** #71# (9)

### 3.5 Turn on/off power

#### Method

**Method 1:** To press **M button one second** (See 5 on Figure1).

**Method 2:** **Master** sends following SMS message to socket in order to set:

Master socket power - ON: #01#0# (10)

Slave socket power - ON: #61#name# (11)

Master socket and all Slave socket power – ON: #01# (12)

Master socket power - OFF: #02#0# (13)

Slave socket power - OFF: #62#name# (14)

Master socket and all Slave socket power – OFF: #02# (15)

### 3.6 Delay control

#### Description

- The socket output can be set to delay switch ON/OFF for a period time.
- Delay control function will auto deactivate once manual change socket status by sending SMS or M button, activate schedule control or temperature control will also deactivate the delay control function.
- When the “delayed switch on the socket” command is received and if the socket output is switched on, the socket output will be switched off immediately and be switch on again as

the setting delayed time is reaching. Contrarily, if the socket output is switched off, the output will remain switching off until the setting delayed time is reaching.

**✘ Method**

**Master** sends following SMS message in order to set:

**Master socket turn on power after certain minutes:** #12#0#Minutes#1# (16)

**Slave socket turn on power after certain minutes:** #63#name#Minutes#1# (17)

**Master socket turn off power after certain minutes:** #12#0#Minutes#0# (18)

**Slave socket turn off power after certain minutes:** #63#name#Minutes#0# (19)

- **Minutes** are time parameters, its range is 1-720,

**Set Master socket delay control – OFF:** #11#0# (20)

**Set Slave socket delay control – OFF:** #63#name#0# (21)

## 3.7 Schedule control

### 3.7.1 Activate schedule control

#### Description

- The socket power can be set to automatically turn on according schedule.
- Schedule control function will auto deactivate if user manually change the socket status by SMS or M button, Delay control or Temperature control will also deactivate schedule control function.

#### Method

**Master** sends following SMS message in order to set:

**Master socket schedule control - ON:** #19#0#1# (22)

**Master socket schedule control - OFF:** #19#0#0# (23)

**Slave socket schedule control - ON:** #64#name#1# (24)

**Slave socket schedule control - OFF:** #64#name#0# (25)



Socket will auto switching on or off the output according to the schedule settings.

### 3.7.2 Set schedule parameters

#### Description

After successful setting of time duration to switch on the socket output, the schedule parameter will be saved on the socket until socket reset to factory settings.

#### Method

**Master** sends following SMS message in order to:

**Set Master socket schedule control time period:**

#20#0#**WorkDay**#**StartTime**#**EndTime**# (26)

**Set Slave socket schedule control time period:**

#65#name#**WorkDay**#**StartTime**#**EndTime**# (27)

- **WorkDay**: one digit, the values lie in the range of “0” to “8”.  
The following table contains the descriptions of each value:

Value	Corresponding day
0	Everyday
1	Monday
2	Tuesday
3	Wednesday
4	Thursday
5	Friday
6	Saturday
7	Sunday
8	Monday to Friday
9	Weekend

- **StartTime** and **EndTime**: Be consists of 4 digits (hh:mm) and works on a 24 hour clock. If **StartTime** bigger than **EndTime**, it will operate until next day EndTime.
- The socket output will switch on at the **StartTime** and cut off at the **EndTime**.
- For example: #20#0#1#0000#2130#, 0 means the SimPal-T40, 0000 means time 00:00 (hh:mm)AM, 2130 means time 21:30. It will turn on power at 00:00, and turn off at 21:30.

## 3.8 Temperature control

### 3.8.1 Activate temperature control

#### Description

- The external temperature sensor must be inserted into the **I/O** port of socket. The socket power output can be auto controlled according environment temperature change.
- Temperature control function will auto deactivate if user manually change the socket status by SMS or M button, Delay control or Schedule control will also deactivate temperature control function.
- There are warming mode and cooling mode for temperature control function. In warming mode, socket will auto turn on when temperature lower than smaller temperature value, and turn off when higher than bigger temperature value; Cooling mode, socket will auto turn on when temperature higher than bigger temperature value and turn off when

temperature lower than smaller value.

#### Method

The **Master** sends following SMS message in order to set:

**Master socket temperature control - ON:** #23#0#1# (28)

**Master socket temperature control - OFF:** #23#0#0# (29)

**Slave socket temperature control - ON:** #66#name#1# (30)

**Slave socket temperature control - OFF:** #66#name#0# (31)

### 3.8.2 Set temperature control parameters

#### Method

**Master** sends following SMS message in order to:

**Set Master socket temp control parameters:** #24#0#mode#low-temp#high-temp# (32)

**Set Slave socket temp control parameters:** #67#name#mode#low-temp#high-temp# (33)

Mode parameter can be 1 or 2, Warming mode is 1, cooling mode is 2;  
Temperature range should be within -10 to 50 degree.

For example #24#0#1#15#25#, it means set SimPa-T40 temperature control parameter, work with warming mode, turn on power when temperature lower than 15 degree, turn off power when temperature higher than 25 degree.

After successful setting of temperature range, the temperature parameter will be saved on the socket until socket reset to factory settings.

### 3.9 Temperature alarm

#### Description

A range of temperature can be pre-set onto each socket. When surroundings temperature is detected out of the pre-set temperature range, the SimPal-T40 will auto-send the SMS

alarm message to your mobile phone.

This feature depends on the temperature sensor.

### Method

**Master** sends following SMS message in order to set:

**Master socket temperature alarm - ON:** #21#0#1# (34)

**Slave socket temperature alarm - ON:** #68#name#1# (35)

**Set Master socket temperature range:** #22#0#MinTemp#MaxTemp# (36)

**Set Slave socket temperature range:** #69#name#MinTemp#MaxTemp# (37)

- **MinTemp** and **MaxTemp**: The values can be set within the range of -10 to 50 centigrade degree.

**Master socket temperature alarm - OFF:** #21#0#0# (38)

**Slave socket temperature alarm - OFF:** #68#name#0# (39)

## 3.10 Wireless sensor alarm

### Description

SimPal-T40 can be working with 6pcs wireless sensor and 2pcs remote control, it can use for alarm functions. Only following sensor can be working with T40:

- WRC-047-F remote control
- WSD-049-F Wireless smoke detector
- WDS-051-F Wireless door sensor
- WIR-053-F Wireless PIR motion detector
- WSI-055-F Wireless strobe siren
- WLD-061-F Wireless water leak detector

There are two types of alarm sensor, one is alarm type, only alarm when T40 alarm function on, the other one is emergency type, it will always alarm even T40 alarm function off. For smoke detector and water leak detector, suggest to pair as emergency type sensor.

 **Method**

**Master** sends following SMS message in order to:

**Pair alarm sensor:** #30#1#Name# (40)

**Pair emergency sensor:** #30#2#name# (41)

**Pair remote control:** #30#3# (42)

**Check pair sensor list:** #30# (43)

**Remove single sensor:** #44#name# (44)

**Remove all wireless sensor:** #44# (45)

**Remove all remote control:** #45# (46)

**Set alarm function - ON:** #40#1# (47)

**Set alarm function - OFF:** #40#0# (48)

**Set schedule alarm function - ON:** #47#1# (49)

**Set schedule alarm function - OFF:** #47#0# (50)

**Set schedule alarm time period:** #46#day#start-time#end-time# (51)

Schedule alarm parameter day time parameters is same as Schedule control.





## 3.12 Power failure alarm

### Description

SimPal-T40 will default sending SMS notify when main power supply lost or restore. It only alert when SimPal-T40 power supply change, SimPal-T20 power supply change will not report.

**Master** can enable/disable this SMS notification.

### Method

**Master** sends following SMS message in order to set:

**SMS when power lost or restore - ON (Default): #05#1#** (56)

**SMS when power lost or restore - OFF: #05#0#** (57)

## 3.13 Calling control

SimPal-T40 default send SMS reply when Master or Family calling to turn on/off power, it can change the setting to calling control without SMS reply.

### Method

**Master** sends following SMS message in order to:

**SMS when calling control – ON (Default): #49#1#** (58)

**SMS when calling control – OFF: #49#0#** (59)

**Calling control function – ON(Default): #09#1#** (60)

**Calling control function – OFF: #09#0#** (61)

### 3.14 SMS notification to User

SimPal-T40 will sending SMS alert when mains power lost/restore, temperature alert or other information. Default sending SMS to both Master and family. Master can change the setting only send SMS to Master number.

#### Method

**Master** sends following SMS message in order to:

**SMS to family number – ON (Default): #16#1#** (62)

**SMS to family number – OFF: #16#0#** (63)

### 3.15 Check status

#### Method

**Master or Family** sends following SMS message in order to:

**Check Master socket operating status:**      #07#      (64)

**Check Slave socket operating status:**      #70#      (65)

After receiving the SMS commands, it will reply SMS message like this:

Main unit: ON    23C  
"Slave1": OFF    30C    T  
"Slave2": ON    23C    C  
"Slave3": ON    25C    D  
"Slave4": ON    25C    D

Socket under "delay control" it will show character "D" after the temperature value, when socket under "Temperature control", it will show character "T" after the temperature value, when socket under "Schedule control", it will show "C" after the temperature value.

**Check Master socket “delayed control” parameters: #34# (66)**

**Check Slave socket “delayed control” parameters: #63#name# (67)**

**Check Master socket “Schedule control” parameters: #33# (68)**

**Check Slave socket “Schedule control” parameters: #64#name# (69)**

**Check Master socket “Temperature control” parameters: #32# (70)**

**Check Slave socket “Temperature control” parameters: #66#name# (71)**

**Check Master socket “Temperature alarm” parameters: #35#0# (72)**

**Check Slave socket “Temperature alarm” parameters: #68#name# (73)**

### **3.16 Weak GSM signal alarm**

The socket can send a SMS notification when the GSM signal strength is too weak. The Master

user can enable/disable this SMS notification.

### Method

The **Master** user sends following SMS message in order to set:

<b>Check GSM signal</b>	<u>#27#</u>	(74)
<b>Weak GSM signal alarm - ON:</b>	<u>#27#1#</u>	(75)
<b>Weak GSM signal alarm - OFF (Default):</b>	<u>#27#0#</u>	(76)

The GSM signal is show as CSQ, CSQ range is 0-31, when CSQ lower than 14, it will set as weak GSM signal. When CSQ lower than 10, device will stop working.

## 4. Reset factory setting

### Description

- This function resets all programmed settings to their original values, including cleaning all user number, timing parameter and temperature parameter.
- If the setting status is wrong or the malfunctions can't be corrected, users can restore the



## 5. Main Technical Parameters

Input power plug	110~230V/50HZ, CEE 7/7 hybrid Schuko/French/American/Australia plug
Output power outlet	110~ 230V/50HZ, 230V/30A(30s), 16A long-duration, CEE7/4 German "Schuko"/ French/ American/Australia
Operating temperature	-10°C~+35°C
Store temperature	-20°C~+50°C
Relative humidity	10-90%, without condensation
Communication protocols	GSM PHASE 2/2+ (including data operation)
Data interface	GSM SIM 1.8V/3.0V socket
RF frequency	433Mhz FSK
Slave socket distance	Up to 30 meters
Temperature sensor range	-10°C~50°C
GSM working band	850/900/1800/1900Mhz (Only T40 support GSM)



## Appendix: SMS commands list

Category	Function	Command
Define the users	Register Master-number	(1) <u>#00#</u>
	Change Master-number	(2) <u>#14#<b>NewMasterNumber#</b></u>
	Add Family-number	(3) <u>#06#<b>Family-Number#</b></u>
	Check Family-number	(4) <u>#06#</u>
	Delete Family-number	(5) <u>#15#<b>Family-Number#</b></u>
	Delete all Family-number	(6) <u>#15#</u>
Pairing T20 slave socket	Pairing slave socket	(7) <u>#60#name#</u>
	Remove slave socket	(8) <u>#71#name#</u>
	Remove all slave socket	(9) <u>#71#</u>
Power control	T40 socket power - ON	(10) <u>#01#0#</u>
	T20 socket power - ON	(11) <u>#61#name#</u>

Category	Function	Command
	All socket power - ON	(12) <u>#01#</u>
	T40 socket power - OFF	(13) <u>#02#0#</u>
	T20 socket power - OFF	(14) <u>#62#name#</u>
	All socket power - OFF	(15) <u>#02#</u>
Delay control	Delay switching ON SimPal-T40 after a certain minutes	(16) <u>#12#0#Minutes#1#</u>
	Delay switching ON SimPal-T20 after a certain minutes	(17) <u>#63#name#Minutes#1#</u>
	Delay switching OFF SimPal-T40 after a certain minutes	(18) <u>#12#0#Minutes#0#</u>
	Delay switching OFF SimPal-T20 after a certain minutes	(19) <u>#63#name#Minutes#0#</u>
	T40 delay control – OFF (Default)	(20) <u>#11#0#</u>
	T20 delay control – OFF (Default)	(21) <u>#63#name#0#</u>
Calendar	T40 schedule control - ON	(22) <u>#19#0#1#</u>

Category	Function	Command
control	T40 schedule control – OFF (Default)	(23) <u>#19#0#0#</u>
	T20 schedule control - ON	(24) <u>#64#name#1#</u>
	T20 schedule control – OFF (Default)	(25) <u>#64#name#0#</u>
	Set T40 schedule control parameters	(26) <u>#20#0#<b>WorkDay#</b> <b>StartTime#EndTime#</b></u>
	Set T20 schedule control parameters	(27) <u>#65#name#<b>WorkDay#</b> <b>Time#EndTime#</b></u>
Temperature control	T40 Temp control - ON	(28) <u>#23#0#1#</u>
	T40 Temp control - OFF (Default)	(29) <u>#23#0#0#</u>
	T20 Temp control - ON	(30) <u>#66#name#1#</u>
	T20 Temp control – OFF (Default)	(31) <u>#66#name#0#</u>
	Set T40 temp control parameters	(32) <u>#24#0#mode#low-temp#high- temp#</u>

Category	Function	Command
	Set T20 temp control parameters	(33) <u>#67#name#mode#low-temp#high-temp#</u>
Temperature alarm	T40 temperature alarm - ON	(34) <u>#21#0#1#</u>
	T20 temperature alarm - ON	(35) <u>#68#name#1#</u>
	Set SimPal-T40 temp range	(36) <u>#22#0#MinTemp#MaxTemp#</u>
	Set SimPal-T20 temp range	(37) <u>#69#name#MinTemp#MaxTemp#</u>
	T40 temperature alarm - OFF (Default)	(38) <u>#21#0#0#</u>
	T20 temperature alarm – OFF (Default)	(39) <u>#68#name#0#</u>
Wireless sensor alarm	Pair alarm sensor	(40) <u>#30#1#name#</u>
	Pair emergency sensor	(41) <u>#30#2#name#</u>
	Pair remote control	(42) <u>#30#3#</u>
	Check sensor list	(43) <u>#30#</u>
	Remove single sensor	(44) <u>#44#name#</u>

Category	Function	Command
	Remove all sensors	(45) <u>#44#</u>
	Remove all remote control	(46) <u>#45#</u>
	Alarm function – ON	(47) <u>#40#1#</u>
	Alarm function – OFF (Default)	(48) <u>#40#0#</u>
	Schedule alarm - ON	(49) <u>#47#1#</u>
	Schedule alarm - OFF (Default)	(50) <u>#47#0#</u>
	Set schedule alarm parameters	(51) <u>#46#day#start-time#end-time#</u>
	Pair wireless siren	(52) <u>#43#</u>
	Set beeper duration	(53) <u>#50#time#</u>
SMS notification	SMS when on/off button pressed - ON (Default)	(54) <u>#03#1#</u>
	SMS when on/off button pressed - OFF	(55) <u>#03#0#</u>

Category	Function	Command
	SMS when power lost or restore – ON (Default)	(56) <u>#05#1#</u>
	SMS when power lost or restore – OFF	(57) <u>#05#0#</u>
Calling control	SMS when calling control – ON (Default)	(58) <u>#49#1#</u>
	SMS when calling control – OFF	(59) <u>#49#0#</u>
	Calling control function – ON (Default)	(60) <u>#09#1#</u>
	Calling control function – OFF	(61) <u>#09#0#</u>
SMS to Users	SMS to Users – ON (Default)	(62) <u>#16#1#</u>
	SMS to Users – OFF	(63) <u>#16#0#</u>
Check status	Check T40 socket status	(64) <u>#07#</u>
	Check T20 socket status	(65) <u>#70#</u>
	Check T40 “Delayed Control” settings	(66) <u>#34#</u>
	Check T20 “Delayed Control” settings	(67) <u>#63#name#</u>

Category	Function	Command
	Check T40 "Schedule control" settings	(68) <u>#33#</u>
	Check T20 "Schedule control" settings	(69) <u>#64#name#</u>
	Check T40 "Temp control" settings	(70) <u>#32#</u>
	Check T20 "Temp control" settings	(71) <u>#66#name#</u>
	Check T40 "Temp alarm" settings	(72) <u>#35#0#</u>
	Check T20 "Temp alarm" settings	(73) <u>#68#name#</u>
	Check GSM signal	(74) <u>#27#</u>
	Weak GSM signal alarm – ON	(75) <u>#27#1#</u>
	Weak GSM signal alarm – OFF (Default)	(76) <u>#27#0#</u>
Reset socket	Reset T40 to factory setting	(77) <u>#08#1234#</u>

